

Chameleon V11/V12 Installation Guide

1. Top sections of each antenna (A) screw into the thicker bottom section of each antenna (B). The V12 will only have one side with (A & B) sections.
2. Antenna elements (A-B) screw into either side of the mount (C).
3. The mount and antenna elements (A-B-C) are attached to a metal mast or side of a tower with the u-bolts (D).
4. Coax is attached to (E) and run to an antenna tuner or radio if there an internal antenna tuner is present. No tuner is necessary for any bands other than the HF bands.

